



SECTION A-A

NOTES

1. LOCK LUG AND SLOTS TO INTERCONNECT ADJACENT CAST IRON PLATES. ALTERNATIVELY THE PLATES CAN BE BOLTED TOGETHER.
2. ALL DIMENSIONS ARE IN mm UNLESS OTHERWISE INDICATED.
3. INSTALL PLATES INTO WET CONCRETE TO FINAL POSITION.
4. PRESS ASSEMBLY INTO WET CONCRETE TO FINAL ELEVATION.
5. SEE STANDARD DRAWING DS-119 FOR DETAILS ABOUT LOCATION OF TACTILE PLATES.

N.T.S.



**Transportation Services**

TACTILE WARNING PLATE

NOVEMBER 2015

DATE

E-6.07